

LN-A37 Large Alligator Clip

LN-A37+1709

Specifications

EN 61010-031:2002+A1:2008 Compliant product

Nominal voltage	1000V
IEC Rating	CATIII 1000V , CATIV 600V
Nominal current	20A
Colour	Black, Red
Connection	2mm Jack
Jaw Opening	34mm
Option feature	Piercing needle

- ✘ LN-A34 With Piercing needle
- ✘ Recommended for use with LN-S05 、 LN-S07 test leads



Beak type design
It is specifically designed for testing in a narrow space.



Incisor
The 3-piece incisor design is helpful for firmly gripping the screw headed or flat headed object to measure.



Piercing needle
This is an optional feature. When the end side of the object to measure is difficult to see, a piercing needle is useful to solve the issue.



Different end connector structures :
There are various end connector structures to fit miscellaneous test probes in the market.

