

HUMIDITY CALIBRATOR

Model : RHA-33, RHA-75

ISO-9001, CE, IEC1010

www.yalab.com.tw

02-2389-0101



Model : RHA-33

33 %RH HUMIDITY CALIBRATOR



Model : RHA-75

75 %RH HUMIDITY CALIBRATOR



LT Lutron

www.YaLAB.com.tw

The Art of Measurement

33 %RH HUMIDITY CALIBRATOR, Model : RHA-33

75 %RH HUMIDITY CALIBRATOR, Model : RHA-75

GENERAL SPECIFICATION

Applications Precision	33% RH, 75% RH CALIBRATION STANDARD for the Humidity Instruments : HT-3003, HT-3004, HT-3005, HT-3006, HA-702, HA-703, HA-704.
Size	Round 70 mm dia. x 52 mm Round 2.8 inch dia. x 2.0 inch.
Weight	120 g (0.3 LB).
Content	RHA-33 Over saturated salt solution of MgCl. RHA-75 Over saturated salt solution of NaCl.

% RH versus TEMPERATURE

33 %RH HUMIDITY CALIBRATOR (33 %RH CALIBRATION STANDARD)

Model : RHA-33 MgCl

Temp. °C	15 °C	20 °C	25 °C	30 °C	35 °C
Temp. °F	59 °F	68 °F	77 °F	86 °F	95 °F
% RH	33.3	33.1	32.8	32.4	32.1

75 %RH HUMIDITY CALIBRATOR (75 %RH CALIBRATION STANDARD)

Model : RHA-75 NaCl

Temp. °C	15 °C	20 °C	25 °C	30 °C	35 °C
Temp. °F	59 °F	68 °F	77 °F	86 °F	95 °F
% RH	75.6	75.5	75.3	75.1	74.9

* Appearance and specifications listed in this brochure are subject to change without notice.

RHA-33, RHA-75+0609

www.YaLAB.com.tw 02-2389-0101