

%RH/O₂/CO₂, one probe Integrating sound level
SD card data recorder

AIR QUALITY METER

Model : AQ-9918SD

ISO-9001, CE, IEC1010

www.yalab.com.tw

02-2389-0101



Lutron

www.YaLAB.com.tw

The Art of Measurement

%RH/O₂/CO₂, one probe Integrating sound level SD card data recorder

AIR QUALITY METER

Model : AQ-9918SD

www.YaLAB.com.tw 02-2389-0101

FEATURE

- * Real time recorder, save the data into the SD memory card and can be downloaded to the Excel, extra software is no need.
- * Air quality measurement, multi-function and only use one probe to cover whole measurement : CO₂ (Carbon dioxide), O₂ (Oxygen), Humidity, Temp..
- * Can show and record multi-probe's input measuring data on the same LCD display at same time.
- * CO₂ range : 0 to 10,000 ppm x 1 ppm.
- * O₂ range : 0 to 30.0 % x 0.1 %.
- * Humidity range : 5 to 95 %RH.
- * Dew point range : -25.3 to 48.9 °C, °C/°F.
- * Temperature range : 0 to 50 °C, °C/°F.
- * CO₂ sensor : NDIR long term reliability.
- * O₂ sensor : Galvanic cell type .
- * Humidity sensor : Precision capacitance sensor.
- * Sampling time for data recorder is 0 to 3600 seconds.
- * Complete set with one multi-function probe.
- * SD card capacity : 1 GB to 16 GB.
- * TFT color LCD, easy reading.
- * Optional acquisition software, SW- US801-WIN, SW-E802.
- * Power by UM3/AA (1.5 V) x 6 batteries or DC 9V adapter.

* Appearance and specifications listed in this brochure are subject to change without notice.

AQ-9918SD+1809

www.YaLAB.com.tw **02-2389-0101**