


VIBRATION METER

Model : VB-8200

ISO-9001, CE, IEC1010

www.yalab.com.tw

02-2389-0101



Lutron



www.YaLAB.com.tw

The Art of Measurement

VIBRATION METER, Model : VB-8200

FEATURES

* Applications for industrial vibration monitoring : All industrial machinery vibrates. The level of vibration is a useful guide to machine condition. Poor balance, misalignment & looseness of the structure will cause the vibration level increase, it is a sure sign that the maintenance is needed.	* Data hold button to freeze the desired reading.
* Frequency range 10 Hz - 1 kHz, sensitivity relative meet ISO 2954.	* Memory function to record maximum and minimum reading with recall.
* Professional vibration meter supply with vibration sensor & magnetic base, full set.	* Separate vibration probe, easy operation
* Velocity measuring range 200 mm/s.	* RS 232 computer interface.
* Acceleration measuring range 200 m/s ² .	* Optional data acquisition software for data record & datalogger.
* RMS & Peak measurement.	* Super large LCD display.
	* Microcomputer circuit, high performance.
	* Auto shut off saves battery life.
	* Built-in low battery indicator.
	* Heavy duty & compact housing case.
	* Complete set with the hard carrying case.

SPECIFICATIONS

Display	61 mm x 34 mm super large LCD display. 15 mm (0.6") digit size.	Sampling time	Approx. 1 second.	
		Data output	RS 232 serial output, isolate.	
Measurement	Velocity, Acceleration RMS value, Peak value Data hold, Max. & Min. value.	Operating temperature	0°C to 50°C (32°F to 122°F).	
		Operating humidity	Less than 80% RH.	
Range	Velocity : 200 mm/s : 0.5 to 199.9 mm/s.	Power supply	Alkaline or heavy duty type DC 9V battery, 006P, MN1604 (PP3) or equivalent.	
	Acceleration : 200 m/s ² : 0.5 to 199.9 m/s ² .	Power consump.	Approx. DC 6 mA.	
Frequency range	10 Hz to 1 KHz. * Sensitivity relative during the the frequency range meet ISO 2954.	Weight	Meter	230 g/0.50 LB
			Probe	38 g/0.09 LB
Accuracy	± (5 % + 2 d) reading , @ 160 Hz, 80 Hz. @ 23 ± 5 °C	Dimension	Meter : 180 x 72 x 32 mm (7.1 x 2.8 x 1.3 inch).	
			Vibration sensor probe: Round 19 mm Dia. x 21 mm.	
Calibration point	Velocity : 50 mm/s (160 Hz) Acceleration : 50 m/s ² (160 Hz)	Accessories included	Instruction manual..... 1 PC. Vibration sensor.....1 PC. Magnetic base..... 1 PC. Carrying Case..... 1 PC.	
Circuit	Exclusive microcomputer circuit.	Optional accessories	* Software (Windows version, data record & data acquisition).....SW-U801-WIN	
Data hold	Freeze the desired reading.		* RS232 cable..... UPCB-01	
Peak hold	To measure the peak value.		* USB cable..... USB-01	
Memory	Maximum & Minimum value.			
Power off	Auto shut off, saves battery life, or manual off by push button.			

* Appearance and specifications listed in this brochure are subject to change without notice.

VB8200+0703