

30 A/300 A/3000 A, 3 ACV at full scale, probe length 600 mm
CP-3001 can cooperate any kinds multimeters (ACmV meters)

3,000A FLEXIBLE CURRENT PROBE

Model : CP-3001

ISO-9001, CE, IEC1010

www.yalab.com.tw

02-2389-0101



CP-3001-R
red connector

CP-3001-Y
yellow connector

CP-3001-B
blue connector



Lutron

The Art of Measurement

www.YaLAB.com.tw

Flexible 3,000 Amp CURRENT PROBE

Model : CP-3001

www.YaLAB.com.tw 02-2389-0101

FEATURES


* Ranges : 30 A/300 A/3000 A, ACA.
* Output voltage : 3 ACV at full scale.
* Flexible probe length : 600 mm (23.6 inch).
* Optional current probe for DW-6093, DW-6095.
* When change the new probe, the calibration procedures are not necessary to be executed.
* Signal output use the banana plugs, durable and safety.
* CP-3001 can cooperate with any kinds of multimeters (ACmV meters) which are built-in the ACV mV measurement range, then can be used as the AC 3000 Amps (max.) current meter.

SPECIFICATIONS

Models	CP-3001-R (red connector). CP-3001-Y (yellow connector). CP-3001-B (blue connector).
Measurement ranges	60 A/600 A/6000 A, 3 ranges, ACA. switch selectable 1st range value : 30 A 2nd range value : 300 A 3rd range value : 3000 A
Output sensitivity	3 ACV at each full scale (30 A, 300 A or 3000 A).
Accuracy	± 1% of range value * Accuracy is specified that the measured conductor's position is on the center of " Flexible current probe". * 50/60 Hz.. * 23 ± 5 °C
Frequency range	45 to 400 Hz. * Accuracy tested under 50/60 Hz.
Linearity	± 0.2 % of reading value from 10 % to 100% of range value.
Phase error	< ± 1.5° * 50/60 Hz..
Conductor position sensitivity	± 2 % of range value. * Recommend the measured conductor position should > 25 mm (1") away from the " Probe locker".
External field influence	increase ± 1.5 % of range value max.. * Recommend the distance between different " Flexibel current probe " should > 200 mm (8").
Enclosure material	UL 94-V0 rated.
Safety	IEC 1010, Categories III 600V.
Power supply	DC 1.5V battery (UM-3/AA) x 2 PCs or DC 9V adapter in.

Power consumption	Approx. DC 9 mA.
Operating Temperature	0°C to 50°C (32°F to 122°F).
Operating Humidity	Less than 80% RH.
Dimension	Main circuit unit : 105 x 56.5 x 33 mm. (4.1 x 2.2 x 1.3 inch). Flexible probe : 600 mm x 14.5 mm DIA. 23.6 inch x 0.57 inch DIA. Cable length: 3.4 meters (11.2 feet). DC plug size : 5.5 mm x 2.5 mm DIA.
Weight	426 g (0.94 LB).
Accessory Included	Operating manual 1 PC.

FRONT PANEL DESCRIPTIONS



* Appearance and specifications listed in this brochure are subject to change without notice.

1209A+CP3001