100 KHz to 3 GHz, 2 probes **3 AXIS RADIO FREQUENCY ELECTROMAGNETIC FIELD METER** Model : EMF-839 ISO-9001, CE, IEC1010

02-2389-0101

www.yalab.com.tw



100 KHz to 3 GHz Radio Frequency Radiation Meters Electromagnetic Field strength measurement

3 AXIS RF ELECTROMAGNETIC FIELD METER

Model : EMF-839

GENERAL SPECIFICATIONS FEATURES 3 Axis probe Wide measuring frequency ranges, 100 KHz to 3 GHz. Radio frequency electromagnetic field teste EMF-839 is used for broadband devices of monitoring the wide range radio frequency electromagnetic field value. For precision measurement consideration, the meter are included two probes : EP-04L (Low frequency Probe, 100 KHz to 100 MHz) EP-03H (High frequency Probe, 100 MHz to 3 GHz) Unit : V/m, W/m^2, mW/cm^2. Alarm setting function can warn the user if the measuring antenna is too near the strong radiation sources, the buzzer will sound to remind the user. Peak hold function to latch peak value. Data hold function to lock the current read RS232 computer interface Real time data logger, build in clock (hour-MIN-sec., vear-month-date). Auto or manual data record, 16,000 Data logger no. Wide sampling time adjustment range from one second to 8 hours 59 minutes 59 seconds. Compact metallic carry case. Large size LCD with contrast adjustment, which can fit best viewing angle. Microcomputer circuit provides special function & offers high accuracy Powered by 006P DC 9V battery or DC 9V adapter.

APPLICATIONS

This meter is specially developed for measuring or monitoring electromagnetic field, for example: cell-phone station, hospital equipment, radar, micro-wave oven, radiation work, TV antenna, Radio station, welding equipment, baking- equipment, television, computer, factory, laboratory, and other environment...etc.

SAFETY INSTRUCTIONS

Danger

- * For worker's safety, be aware that persons with electromagnetic implant (e.g. cardiac-pacemarker) are subject to especial danger in some case.
- Particular to observe the local safety regulations of the operator of the equipment.
- * Before using the device, it need to know that how to setting " alarm-limit " value.

Attention

- * Claims by some scientists that long term exposure to electromagnetic field may be the cause of childhood leukemia & other forms of cancer.
- ^k Complete answers to any of these and related
- questions are not currently available. At the present time the most common practice is to avoid excess exposure over long period of time.
- ^k Complete answers to any of these and related " Prudent Avoidance " as stated by the Environmental Protection Agency(EPA) USA is recommended.
- According to ICNIRP of reference levels to time-varying

electromagnetic fields, The E-field strength levels are:

General public

Frequency range	e-field strength (V/m)
3 to 150 kHz	87
0.15 to 1 MHz	87
1 to 10 MHz	87/f^1/2
10 to 400 MHz	28
400 to 2000 MHz	1.375 x f^1/2
2 to 300 GHz	61

Occupational

Frequency range	e-field strength (V/m)			
65 to 1000 kHz	610			
1 to 10 MHz	610/f			
10 to 400 MHz	61			
400 to 2000 MHz	3 x f^1/2			
2 to 300 GHz	137			

* Appearance and specifications listed in this brochure are subject to change without notice.

Circuit Custom one-chip of microprocessor LSI circuit. LCD size : 58 mm x 34 mm Display //m, mW/cm^2, W/m^2. Measurement Unit Accuracy < 2 dB Probe structure 3 Axis EP-03H : 100 MHz to 3 GHz. Probe Type EP-04L : 100 kHz to 100 MHz. Selection Probe Input 50 OHM Impedance EP-03H: 900 MHz, 1 GHz, 1.8 GHz, Frequency 2.4 GHz, 2.45 GHz, 3 GHz Selection EP-04L: 100kHz, 200kHz, 500kHz, 1MHz, Points 10MHz, 13.56MHz, 100MHz. Sensor Semiconductor Structure Sampling Time Manual Press the data logger button once will save data one time. of Data Logger * Set the sampling time to 0 second 1 sec to 8 hour 59 min. 59 sec. Auto Data Hold Freeze the display reading. **REC** Function Record Maximum & Minimum value. Power off Auto shut off saves battery life or manual off by push button. Can default auto power off or manual power off. When default auto power off, power will off automatically after 10 min. if no button be pressed. Peak Hold To latch the peak measurement value Alarm Setting Buzzer will sound when display over the setting value. Approx. 1 second. Sampling Time Low Battery When display show Low battery Indicator, it should change the batteries. Indicator RS 232 PC serial interface. Data Output Operating 0 to 50 °C <u>Temperature</u> less than 80 %RH. Operating Humidity Power Supply DC 9 V battery (006P) * Heavy duty or Alkaline type. DC 9V adapter input Approx. DC 5.95 mA Power Curren Weight 523 g/ 1.16 LB Dimension Main instrument 200.0 x 76.2 x 36.8 mm Probe : 70 mm (diameter) x 290 mm (length) Instruction manual.....1 PC Accessories Included EP-03H Probe..... 1 PC EP-04L Probe..... 1 PC Memory card for EP-03H..... 1 PC Memory card for EP-04L..... 1 PC DC 9V power adapter..... 1 PC Metal carrying case..... 1 PC RS232 cable, UPCB-02. Optional

ELECTRICAL SPECIFICATIONS (23 ± 5 °C)

Strength Range	Resolution		Effective Value		
0~200.00 V/m	0.01 V/m 0.001 W/m^2		> 1 V/m > 0.03 W/m^2		
0~99.999 W/m^2					
0~9.9999 mW/cm^2	0.0001 mW/cm^2		> 0.0003 mW/cm^2		
Frequency range	Accuracy	Cal. level		Probe no.	
*100 KHz to 100 MHz	< 2 dB	30 V/ı	n	EP-04L	
*50 MHz to 3 GHz	< 2 dB	60 V/m		EP-03H	
Demonster					

JSB cable, USB-01.

Data Acquisition software, SW-U801-WIN.

Data Logger software, SW-DL2005.

Remark:

Accessories

- * EP-04L probe's accuracy is specified within 400 KHz to 100 MHz only. If measurement frequency range is < 400 KHz, the reading value just for reference only.
- * EP-03H probe's accuracy is specified within 100 MHz to 2.5 GHz only. If measurement frequency range is < 100 MHz or > 2.5 GHz, the reading value just for reference only.
- * For precision measurement consideration, it should select the " Frequency Team point " near the frequency value of measuring object.

0906-EMF839

www.YaLAB.com.tw

NCC (National Communication Commission is the official organization on behalf Taiwan government)

NCC RECOMMEND EMF-839, EMF-819 for Mobile station measurement

The correct instrument for mobile station measurement



NCC Website : http ://www.ncc.gov.tw